



Energize

Commercial Dishmachine Detergent

Dishwashing

Description

Energize is a highly concentrated powder commercial dishmachine detergent. Works for both high temperature and low temperature dishmachines. Energize has the power to remove grease, oils, and tough food deposits while preventing stains and protein buildup on wares.

Safe and effective on all machine washable items including glasses, dishes, utensils, and plastic ware.

Directions for Use

Energize is designed to be automatically dispensed from shipping container. To use, remove shipping lid making sure to leave screen cap on. Place product, screen cap down, into the detergent bowl.

Concentrations should be set up, adjusted, and monitored by a trained service professional to ensure best results.

Safety Cautions

- Keep out of reach of children
- Prior to using this or any cleaning product, make sure employees read and understand the hazard information found on the product label and Safety Data Sheet (SDS). The label and SDS will also provide information on handling precautions, protective equipment and first aid instructions which might be appropriate for this product.

Features & Benefits

- Quickly activates to emulsify grease and food soils
- Slightly chlorinated for destaining
- Contains defoaming agents
- Will not harm dish finishes
- Effective in hard or soft water
- Metal safe

Specifications

Appearance:	White powder
Odor:	Slight chlorine odor
PH:	13
Biodegradable:	Yes
Detergency:	Excellent

Dilution

Based on environmental conditions, dilutions will vary to achieve a use pH of 10.5-12.

Available Sizes

4X9lb. Jars Per Case / Item # 0375